

All rights reserved! Any company or individual person shall not copy or backup this user manual in any format (electronic, mechanical, photocopying, recording or other formats) without written permission from Launch Tech Co., Ltd (hereinafter referred to as "Launch"). The manual is for the use of the products manufactured by Launch, which shall not assume any responsibility for the consequences arising from the use of it to guide the operations of other equipment.

Launch and its branches will not bear any liability for the fees and expenses incurred by equipment damage or loss due to accidents caused by users or third parties, misuses and abuses, unauthorized modifications and repairs, or operations and services not following launch's instructions.

Launch assumes no responsibility for device damages or problems resulted from the usage of other parts or consumables, rather than original products of launch or products approved by the company.

Official statement: the mentioning of the names of other products in this manual is to illustrate how to use the device, with the ownership of the registered trademarks belonging to the owners.

The device is intended for the use of professional technicians or maintenance and repair personnel.

#### **Registered Trademark**

Launch has registered its trademark in china and several other countries, and the logo is . Other trademarks, service marks, dot names, icons, company names of launch **LAUNCH** in the user manual all belong to launch and its subsidiaries. In those countries where trademarks, service marks, dot names, icons, company names of launch have not been registered yet, launch disclaims the right for its unregistered trademarks, service marks, dot names, icons, and company names. Trademarks of other products and company names mentioned in this manual are still owned by the original registered companies. Without written agreement from the owner, no person is allowed to use the trademarks, service marks, domain names, icons and company names of Launch or of other mentioned companies. You can visit [www.cnlaunch.com](http://www.cnlaunch.com), or write to Customer Service Center of Launch Tech Co., Ltd at Launch Industrial Park, North of Wuhe Avenue, Banxuegang, Longgang District, Shenzhen, P.R. China, to get contact with Launch for the written agreement on the usage of the user manual.

#### **Disclaimer of Warranties and Limitation of Liabilities**

All information, illustrations, and specifications in this manual are based on the latest information available at the time of publication.

The right is reserved to make changes at any time without notice. We shall not be liable for any direct, special, incidental, indirect damages or any economic consequential damages (including the loss of profits) due to the use of the document.

**This manual uses the following conventions.**

In this manual, we refer to low voltage and high voltage as LV and HV for short.

To avoid personal injury, property damage, or accidental damage to the product, please read all information in this chapter before using the product.

**Operating Regulation and Requirements for HV Equipment**

- (1) Please read this manual carefully and operate the equipment in accordance with relevant guidelines and safety regulations.
- (2) During maintenance, it is required to wear necessary safety protection articles with a voltage resistance level greater than 1000V.
- (3) When disassembling, connecting and operating HV appliances and equipment, attention shall be paid to whether the protection of sheet metal on the vehicle body is normal to avoid wear.
- (4) When installing connectors and terminals of HV components, please ensure that the connectors are properly installed and confirm that connection is reliable.
- (5) During maintenance, please try to use one hand.
- (6) When using digital power, please keep the station dry, bright, and ventilated to prevent electric shock accident caused by the damp environment
- (7) In case of abnormal accident or fire, operators shall immediately cut off HV and LV circuits, evacuate personnel, and extinguish the fire with the fire extinguisher and fire sand under the condition of ensuring their own safety.
- (8) During power output of digital power, please do not operate the equipment or connect the cable harness with power on.
- (9) Improper use of digital power may cause personal injury.




## Contents

|                                             |           |
|---------------------------------------------|-----------|
| <b>1. Packing List .....</b>                | <b>1</b>  |
| <b>2. Product Introduction .....</b>        | <b>2</b>  |
| 2.1 Overview .....                          | 2         |
| 2.2 ELA400.....                             | 2         |
| <b>3. Technical Parameters .....</b>        | <b>5</b>  |
| <b>4. Equipment Operation .....</b>         | <b>6</b>  |
| 4.1 Equipment Startup.....                  | 6         |
| 4.2 LV Output .....                         | 6         |
| 4.3 HV Output.....                          | 6         |
| <b>5. APP Operation.....</b>                | <b>8</b>  |
| 5.1 APP Launching.....                      | 8         |
| 5.2 Bluetooth Button .....                  | 9         |
| 5.3 LV Output .....                         | 10        |
| 5.4 HV Output.....                          | 10        |
| 5.5 Exit .....                              | 11        |
| <b>6. Equipment Protection .....</b>        | <b>13</b> |
| 6.1 Power Output Protection Mechanism ..... | 13        |
| 6.2 LV Output Protection Mechanism .....    | 13        |
| 6.3 HV Output Protection Mechanism .....    | 13        |
| <b>7. Maintenance.....</b>                  | <b>14</b> |
| <b>FCC Warning.....</b>                     | <b>15</b> |



## 1. Packing List

The following accessories are for reference only. Please consult from the local agency or check the package list supplied with this equipment together.


| Main Unit and Accessories |                                      |      |                                                                                              |
|---------------------------|--------------------------------------|------|----------------------------------------------------------------------------------------------|
| NO.                       | Name                                 | Q'TY | Reference Picture                                                                            |
| 1                         | Main Unit                            | 1    |             |
| 2                         | AC Power Cord                        | 1    |             |
| 3                         | HV Extension Cable                   | 1    |             |
| 4                         | HV Wire<br>(Alligator Clip-Fits)     | 1    |             |
| 5                         | HV Jumper Cable<br>(4mm Banana Plug) | 1    |             |
| 6                         | LV Wire<br>(Alligator Clip-Fits)     | 1    | <br>(Black) |
|                           | LV Wire<br>(Alligator Clip-Fits)     | 1    | <br>(Red) |
| 7                         | User Manual                          | 1    | -                                                                                            |
| 8                         | Packing list                         | 1    | -                                                                                            |

## 2. Product Introduction


### 2.1 Overview

ELA400 Intelligent Digital Power Supply for automobile maintenance is a dual-output switching DC stabilized voltage supply developed by Launch for both new energy vehicles and fuel vehicles. This product has stable current output, excellent performance indicators, and a variety of protection mechanisms. It is a smart digital power supply dedicated to auto repair, which is safe and easy to use, and supports Bluetooth control.

### 2.2 ELA400



Front View



Rear View

| No. | Name and Description                                                                                                                                                                                                         |
|-----|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1   | <b>Handle</b>                                                                                                                                                                                                                |
| 2   | <b>Buzzer Hole</b><br>The buzzer will keep sounding when the HV output.                                                                                                                                                      |
| 3   | <b>Display Area for LV Voltage Value</b><br>When LV output is not started, the current voltage set is displayed. When LV output is started, the output voltage is displayed.                                                 |
| 4   | <b>Display area for LV Current Value</b><br>The current set current is displayed when the high-voltage output is not started, and the actual output current is displayed after the high-voltage output is started.           |
| 5   | <b>LV ON/OFF Button</b><br>Turn on/off LV output. Under LV output, the LED light (green) of the button is always on; When the LV output is not output, the LED light (green) of the button is off.                           |
| 6   | <b>Adjusting Knob for LV Voltage</b><br>This knob is used to adjust the set LV value. The voltage can be adjusted from 0~50V.                                                                                                |
| 7   | <b>Adjusting Knob for LV Current</b><br>This knob is used to adjust the set LV current value. The current can be adjusted from 0 to 15A.                                                                                     |
| 8   | <b>Positive Electrode of LV Output Port (Red)</b>                                                                                                                                                                            |
| 9   | <b>Negative Electrode of LV Output Port (Black)</b>                                                                                                                                                                          |
| 10  | <b>Adjusting Knob for HV Voltage</b><br>This knob is used to adjust the set HV value. The voltage can be adjusted from 50~900V.                                                                                              |
| 11  | <b>Adjusting Knob for HV Current</b><br>This knob is used to adjust the set HV current value. The current can be adjusted from 0 to 5A.                                                                                      |
| 12  | <b>HV ON/OFF Button</b><br>Start/Stop HV output. Under HV output, the LED light (orange) of the button is always on; When the HV output is not output, the LED light (orange) of the button is off.                          |
| 13  | <b>HV Output Port</b><br>It includes HV positive and negative electrode interface, a dustproof cover, fool-proof and anti-reverse connection design.                                                                         |
| 14  | <b>Circuit Breaker</b><br>Push the circuit breaker handle up to turn on the power switch of the equipment, and pull the handle down to turn off the power switch of the equipment.                                           |
| 15  | <b>Bluetooth Indicator</b><br>After the equipment is powered on, the Bluetooth indicator is always on, and the indicator will continue to flash after establishing a bluetooth connection with external detection equipment. |

|    |                                                                                                                                                                                                                    |
|----|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 16 | <b>Power Indicator</b><br>After connecting the power supply and pushing up the circuit breaker handle of the equipment to turn on the power switch of the equipment, this indicator will be on.                    |
| 17 | <b>Display Area for HV Current Value</b><br>The current set current is displayed when the high-voltage output is not started, and the actual output current is displayed after the high-voltage output is started. |
| 18 | <b>Display Area for HV Voltage Value</b><br>When HV output is not started, the current voltage set is displayed. When HV output is started, the output voltage is displayed.                                       |
| 1  | <b>Power Supply Input</b>                                                                                                                                                                                          |
| 9  | <b>Air Vent for Heat Dissipation</b><br>Air vent of cooling fan, with a dust screen.                                                                                                                               |
| 2  | <b>Air Inlet for Heat Dissipation</b>                                                                                                                                                                              |
| 21 | Air inlet of cooling fan, with a dust screen.                                                                                                                                                                      |

### 3. Technical Parameters

| Technical Indexes |                                  |                                                                                                                                                                  |
|-------------------|----------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PowerSupplyInput  |                                  | AC100~240V50±10Hz20A                                                                                                                                             |
| Power             |                                  | 4kWMax                                                                                                                                                           |
| HV<br>Parameters  | VoltageRange                     | 50~900V                                                                                                                                                          |
|                   | CurrentRange                     | 0~5A                                                                                                                                                             |
|                   | VoltageSamplingAccuracy          | 1V                                                                                                                                                               |
|                   | CurrentSamplingAccuracy          | 0.1A                                                                                                                                                             |
|                   | OutputProtection                 | Current-limiting protection, short-circuit protection, undervoltageprotection, overvoltageprotection, and overtemperature protection                             |
|                   | InputProtection                  | Overvoltageprotection, short-circuitprotection, and undervoltage protection                                                                                      |
|                   | InsulationImpedance              | Input-output: DC500V 10MΩ Min (Ambient temperature)<br>Input-earth: DC500V 10MΩ Min (Ambient temperature)<br>Output-earth: DC500V 10MΩ Min (Ambient temperature) |
|                   | Insulation and Resisting Voltage | Input-output: 2000Vac 50Hz (2828Vdc) 1 minute<br>Input-earth: 2000Vac 50Hz (2828Vdc) 1 minute<br>Output-earth: 2000Vac 50Hz (2828Vdc) 1 minute                   |
| LV<br>Parameters  | VoltageRange                     | 0~50V                                                                                                                                                            |
|                   | CurrentRange                     | 0~15A                                                                                                                                                            |
|                   | OutputProtection                 | Short-circuitprotection                                                                                                                                          |
|                   |                                  | Not exceeding 2000m                                                                                                                                              |
| Environment       | Altitude                         | II(GB16895.12)                                                                                                                                                   |
|                   | OvervoltageCategory              | II                                                                                                                                                               |
|                   | PollutionDegree                  | -10~65℃                                                                                                                                                          |
|                   | WorkingTemperature               | -40~70℃                                                                                                                                                          |
|                   | StorageTemperature               | 5~95%Relativehumidity(nocondensation)                                                                                                                            |
|                   | WorkingEnvironmentHumidity       | 395x331x265mm                                                                                                                                                    |
| Dimension         |                                  |                                                                                                                                                                  |

## 4. Equipment Operation

### 4.1 Equipment Startup

(1) Pull down the circuit breaker handle.

(2) After confirming that voltage of input power supply is correct, connect two ends of the power cord to the power socket and the power input respectively.

(3) Push up the circuit breaker handle to switch on the power switch.

*Note: After the equipment is powered on for the first time, the default LV output is 12V 5A, and the default HV output is 200V 1A.*

### 4.2 LV Output

(1) Rotate the LV current adjusting knob and the LV voltage adjusting knob to set the required current and voltage values.

(2) Insert a red LV test wire into the positive electrode of the LV output, and connect the other end to the positive electrode of the device to be tested; Insert the black LV test wire into the negative electrode of the LV output, and connect the other end to the negative electrode of the device to be tested.

(3) After pressing the LV ON/OFF button, the LED light (green) of the button is always on, and the digital power supplies power to the device under test according to the set parameters.


(4) If it is required to stop the LV output, press the LV ON/OFF button again. The LED light of the button (green) will be off, and the digital power will close the LV output.

*Note: The voltage cannot be adjusted during the LV output of the equipment; If it is required to adjust the voltage, please stop the LV output of the equipment and set it again.*


### 4.3 HV Output

(1) Rotate the HV current adjusting knob and the HV voltage adjusting knob to set the required current and voltage values.

(2) Remove the dust-proof cover of the HV output port, and insert one end of the HV extension cable into the HV output port (with a fool-proof anti-reverse insertion design, the positive and negative signs on the plug are consistent with the positive and negative signs on the output port before inserting).



(3) Select the corresponding high-voltage test wire (alligator clip-fits HV wire or banana plug HV jumper cable) as needed. Connect one end of the test wire to the HV extension cable, connect the red wire at the other end of the test wire to the positive pole of the device under test, and the black wire at the other end to the negative pole of the device under test.



(4) After pressing the HV ON/OFF button, the LED light (orange) of the button is always on, the buzzer keeps sounding, and the digital power supply supplies power to the device under test according to the set parameters.

*Note: The voltage and current cannot be adjusted during the HV output of the equipment; if it is required to adjust the voltage and current, stop the HV output of the equipment and set them again.*

(5) If it is required to stop the HV output, press the HV ON/OFF button again. The LED light of the button (orange) will be off, and the digital power supply will close the HV output.

*Note: When not using the HV output function of digital power supply, it is advised to cover the dust-proof cover to protect the HV output interface and prevent accidental touch.*


## 5. APP Operation

In addition to operating directly on the main unit, ELA400 can also be used with other detection device to operate via Bluetooth wireless connection.


### 5.1 APP Launching

(1) Tap **Digital Power** on the detection device to launch the APP.

(2) After the APP is started, the safety prompt page of "Operating Regulation and Requirements for HV Equipment" is displayed.



(3) Tap **Next** to enter the operation interface of digital power supply.



| No. | Name and Description                                                                                                                                    |
|-----|---------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1   | <b>Exit</b><br>Tap this button to exit the APP.                                                                                                         |
| 2   | <b>Display Area for LV Voltage Value</b><br>Display the actual output voltage value of the LV output port.                                              |
| 3   | <b>Display Area for LV Current Value</b><br>Display the actual output current value of the LV output port.                                              |
| 4   | <b>LV Voltage Adjusting Knob</b><br>Slide digital up and down to set the LV output voltage.                                                             |
| 5   | <b>LV Current Adjusting Knob</b><br>Slide digital up and down to set the LV output current.                                                             |
| 6   | <b>LV ON/OFF Button</b><br>Start/Stop LV output.                                                                                                        |
| 7   | <b>HV Voltage Adjusting Knob</b><br>Slide digital up and down to set the HV output voltage.                                                             |
| 8   | <b>HV Current Adjusting Knob</b><br>Slide digital up and down to set the HV output current.                                                             |
| 9   | <b>HV ON/OFF Button</b><br>Start/Stop HV output.                                                                                                        |
| 10  | <b>Display Area for HV Current Value</b><br>Display the actual output current value of the HV output port.                                              |
| 11  | <b>Display Area for HV Voltage Value</b><br>Display the actual output voltage value of the HV output port.                                              |
| 12  | <b>Duration of HV Test</b><br>After pressing the HV ON/OFF button, the timing indicator will be on and the timing will start. The of duration is h/m/s. |
| 13  |                                                                                                                                                         |

### Bluetooth Button

## 5.2 Bluetooth Button


Tap this button to view or set the Bluetooth.

(1) Tap the Bluetooth button in the upper right corner (the icon is shown as



when

Bluetooth is not connected) to pop up the device selection window, and select the serial number of the current digital power supply for connection.



(2) After the Bluetooth is connected, "Bluetooth connected. Synchronizing data..." is displayed on the screen, and the Bluetooth icon is shown as  in the top right corner.



(3) After data synchronization, settings and operations can be performed on both the detection device and the digital power supply, subject to the final operation.

### 5.3 LV Output

(1) Slide the "LV Current Adjustment Knob" and "LV Voltage Adjustment Knob" up and down to set the LV current and voltage value respectively, and then tap the "LV ON/OFF Button", the digital power supply will supply power to the device under test according to the set parameters.


(2) If it is required to stop the LV output, Tap the "LV ON/OFF Button" again.

### 5.4 HV Output

(1) Slide the "HV Current Adjustment Knob" and "HV Voltage Adjustment Knob" up and down to set the HV current and voltage value respectively, and then tap the "HV ON/OFF Button".

(2) The pop-up window prompts the current setting parameters. Tap **OK** after checking the

parameters and confirming that the HV harness is connected normally.




(3) At this time, the buzzer continue to sound, and the digital power supply will supply power to the device under test according to the set parameters.



(4) If it is required to stop the HV output, tap the "HV ON/OFF Button" again.

## 5.5 Exit

Tap  in the upper left corner of the screen to exit the APP. If the digital power supply is in the output state, Tap the  button and "Digital power output, exit or not" is displayed on the popup of the screen, and Tap **Yes** to confirm exit.



*Note: Digital power supply output is not affected after exiting the APP. The digital power output can be turned off only after the "LV ON/OFF button" and "HV ON/OFF button" are turned off.*

## 6. Equipment Protection

### 6.1 Power Input Protection Mechanism

The ELA400 protects the input circuit through a circuit breaker. When the fault protection is triggered, the circuit breaker will automatically cut off the power supply of the equipment.

### 6.2 LV Output Protection Mechanism

When the LV part triggers fault protection, the digital power supply will automatically cut off the output and prompt the corresponding fault code, and return to the default state. The fault information is described in the following table:

| Fault name               | Fault Code | Handling Mechanism (recommended)                            |
|--------------------------|------------|-------------------------------------------------------------|
| Short-circuit protection | E01        | Stop output immediately, and prompt to check the equipment. |

### 6.3 HV Output Protection Mechanism

When the HV part triggers fault protection, the digital power supply will automatically cut off the output and prompt the corresponding fault code, and return to the default state. The fault information is described in the following table:

| Fault Name                 | Fault Code | Handling Mechanism (Recommended)                          |
|----------------------------|------------|-----------------------------------------------------------|
| AC Overvoltage             | E01        | Check input connections and AC voltage.                   |
| AC Undervoltage            | E02        | Check input connections and AC voltage.                   |
| Output Overvoltage         | E03        | Stop output immediately, and prompt to check the          |
| Output Undervoltage        | E04        | equipment.                                                |
| Output Overcurrent         | E05        | No risk to the module. Determine by yourself according to |
| Output Short-circuit       | E06        | the equipment                                             |
| Overtemperature Protection | E07        | safety.                                                   |
| Hardware Fault             | E08        | Stop output immediately, and prompt to check the          |
| No Equipment Connected     | E09        | equipment.                                                |
| Equipment Polarity Reverse | E10        | Stop output immediately, and prompt to check the          |
| PFC derating Caused by     | E11        | equipment.                                                |
| Overtemperature            | E12        | Stop output immediately, and prompt to check the          |
| Fan Derating Caused by     | E13        | equipment.                                                |
| Overtemperature            |            | Stop output immediately, and prompt to check the          |
| Derating at a Higher       |            | equipment.                                                |
| Temperature                |            | No risk. Determine by yourself according to the equipment |

safety.

Stop output immediately, and prompt to check the equipment.

## 7. Maintenance

- (1) When the input power is short circuited, the air switch will automatically trip. Please disconnect the power switch, unplug the power cord, and have a professional check.
- (2) When there is a short circuit or other malfunction in the LV power supply, please disconnect the power switch, unplug the power cord, and have a professional check.
- (3) When there is a short circuit or other malfunction in the HV power supply, please disconnect the power switch, unplug the power cord, and have a professional check.
- (4) If the malfunction is severe and cannot be resolved, please contact your local dealer or our company.

## **FCC Warning**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.