



## ***FEATURES***

- Use “U” Sleeve or Two Jaws Hook to Fix the Injector and Then Pull Out with Slide Hammer.
- Applicable: VW, Audi FSI Engines