



FEATURES

- Effective tool for installing CV clamps.
- The standard banding tool works with the installer's ratchet and 1/2" socket, or use the provided lever to tension the clamp.
- When the boot clamp has been tightened to specs cut the band to the correct length by flipping the lever forward.