



## ***FEATURES***

- Diesel Engine Setting/Locking Kit
- Suitable for timing Mercedes CDi and Chrysler CRD chain drive diesel engines.
- Features flywheel locking plates with M6x90mm bolts and a camshaft locking pin set.
- Individual tools are also suitable for many other Mercedes petrol and diesel engines.
- Supplied in storage case.

## ***SPECIFICATIONS***

- OEM Tools: 111589031500/8929, 601589024000/8932, 602589004000/8933
- Applications (1): Mercedes; CDi – C-Class 2.0 (03-08), 2.2 (98-04), 2.2 (03-08), 2.2 (07-09), 2.7 (00-06), CLK 2.2 (05-09), 2.7 (02-06),
- E-Class 2.0 (02-09), 2.2 (98-03), 2.2 (02-09), 2.7 (98-03), 2.7 (02-09), 3.0 (02-09), 3.2 (98-03), 3.2 (02-09),
- G-Wagen 2.7 (01-05), M-Class 2.7 (99-05), S-Class 3.2 (99-03), 3.2 (02-06), Sprinter 2.7 (99-06), V-Class 2.2 (99-03),
- Viano 2.0 (03-09), 2.2 (03-09), Vito 2.2 (99-03), 2.2 (03-09)
- Applications (2): Chrysler; CRD – PT Cruiser 2.2 (02-08),
- Jeep Grand Cherokee 2.7 (01-05)
- Engine Codes (1): 611.960/961/962/980, 612.961/962/963/965/967/981 613.960, 646.811/ 812/951/961/962/963/820/821/982/983/966, 647.961/982, 648.960/961, EDJ
- Engine Codes (2): EDJ