



FEATURES

- Ideal for internal and external pulling on bearing cups, stubborn oil seals and many press fitted parts.
- Open 3 jaw internal or external puller and clip on bearing, Then use the slide hammer to pull the bearing out.

SPECIFICATIONS

- Size: Internal Puller: 15 ~ 30 mm
- Internal Puller: 30 ~ 80 mm
- External Puller: 15 ~ 80 mm