



FEATURES

- Oxygen Sensor Socket Set 7 Piece (O2 Sensor Oil Pressure Sending Unit)
- For removal or replacement of heated and non-heated oxygen sensors.
- Cut-away sections for use in tight spaces.

SPECIFICATIONS

- 1/2" x 27mm injector socket,
- 3/8" x 7/8" vacuum switch socket,
- 2 piece oxygen sensor sockets (1/2" x 29mm and 3/8" x 7/8"),
- 3/8" x 7/8" offset oxygen sensor wrench,
- 3/8" x 1-1/16" oil sensor unit socket,
- 1/2" x 22mm heated oxygen sensor socket.