# METAL CASED CHARGER / STARTERS

| TradeCharge40T<br>RCBT40T<br>40amp, 12/24V Trolley Charger<br>280 amp Engine Start | TradeCharge55T<br>RCBT55T<br>55amp, 12/24V Trolley Charger<br>420 amp Engine Start |
|---|---|
|  |  |

## Features

| | | |
|---|---|---|
| Charging Current (eff) | 40 Amps | 55 Amps |
| Star ting Current (eff ) | 280 Amps | 420 Amps |
| Outputs for 12V & 24V batteries | a | a |
| Charge rate display | Digital | Digital |
| Fully Insulated Clamps | a | a |
| Charge Rate Settings | 4 | 6 |

## Specification

| | | |
|---|---|---|
| AC Input Voltage | 230V | 230V |
| AC Input Power | 1200/2000W | 1400/2600W |
| Charge current (peak) | 55A | 80A |
| Charge current (effective RMS) | 40A | 55A |
| Charge current (arithmetic/EN) | 30A | 40A |
| Star t current ( peak) | 400A | 600A |
| Star t current (effective RMS) | 280A | 420A |
| Star t current (arithmetic/EN) | 200A | 350A |
| Cranking ON cycle (sec) | 5 | 5 |
| Cranking Off cycle (sec) | 30 | 30 |
| Cranking cycles (max) | 5 | 5 |
| Battery Capacity | 50-400Ah | 50-600Ah |
| Output fuse | 1 x 50A | 2 x 50A |
| Dimension(mm) | 553x293x207 | 640x353x270 |
| Weight (Kg) | 21 | 28 |